

The water flows little or not back into the pool.

Sarah Tichler - 2019-04-03 - 0 Comments - in Kartuschenfilteranlage

Check the cartridge filter for the degree of soiling, clean it with a garden hose or replace it with a new filter.

Check the water level and the height of the surface skimmer, if the water level is too low, too little water flows into the pump.

Vent the system. Open the air release valve on the lid until water runs out.