

Portal > Knowledgebase > Informationen rund um die Poolwelt > Poolroboter > The cleaner shows no function.

The cleaner shows no function.

Sarah Tichler - 2019-04-04 - 0 Comments - in Poolroboter

Check the plug of the mains cable and the control unit.

Plug the control unit directly into a power outlet and do not use extension cords.

Check your house power line for overload, possibly the socket has a defect.

Contact a qualified electrician to correct the electrical fault.