

The pump can not be activated.

Sarah Tichler - 2019-04-03 - Sandfilteranlage

Check your electrical outlet for power, try another outlet if necessary.

1. Never run the pump without water, the pump can run dry and burn off.
2. Check the mains plug or connecting cable for damage.