

## Error code E94 - The water temperature is too low

Sarah Tichler - 2019-04-04 - Whirlpools

If the ambient temperature is below 4°C, we recommend not to use the spa.

Turn off and unplug the power plug of the control unit.

Add some warm water to raise the water temperature of the spa to over 5 ° C, then press the button to warm the water to the desired temperature.