

Air in the sand filter system.

Sarah Tichler - 2019-04-03 - in Sandfilteranlage

Fill the pump with water, loosen the transparent cover on the filter container (not completely unscrew) to remove trapped air.

Retighten the cover when all air has escaped.

Check all connections and hoses for leaks or holes.

Tighten connections or hose clips, seal with Teflon tape and, if necessary, replace the defective parts.